

INSTRUCTION SHEET FOR MODEL #LRK/SLRK

Tools Required: Screw Driver or Power Screw Driver

Step 1. Determine desired length and height of your Log Rack. Cut four (4) 2 x 4's to the desired height to become the four (4) vertical supports and cut two (2) additional; 2 x 4's to the desired length to become the bottom horizontal supports.

Step 2. Carefully remove all contents from the package. The package will contain two (2) End Brackets and a package of twenty (20) screws.

Step 3. Place the Brackets on the ground with the opening of the "U" shapes facing each other. The distance between them should be approximately the length of the 2 x 4's that are the bottom supports.

Step 4. Insert a vertical support 2 x 4 into the inside corner in one of the End Brackets. While holding the 2 x 4 vertical, insert two (2) screws through the predrilled holes in the End Bracket and tighten to firm up the 2 x 4. Insert two (2) screws into the predrilled holes on the backside of the End Bracket and tighten.

Step 5. In the same corner which you have installed the vertical support 2 x 4, insert a horizontal 2 x 4 support and butt it to the vertical support 2 x 4. Insert one (1) screws into the predrilled holes on the side of the End Bracket and tighten to the horizontal support.

Step 6. Repeat Step 5 on the opposite end of the End Bracket you are working on and then repeat Step 4 & 5 on both corners of the other End Brackets.

