

INSTRUCTION SHEET FOR MODEL #'S LR42, LR44, SL42, LR48, SLR44 & SLR48

Parts List			
Part Number	Part Description	Model LR42, LR44, SLR42, SLR44 Quantity	Model LR48, SLR48 Quantity
A	End Frame	2	2
B	Bottom Frame	2	4
C	Hex Head Bolt	8	12
D	Hex Head Nut	8	12
E	Plastic Cap	8	12

Tools Required: Adjustable wrench and pliers

Step 1. Carefully remove all contents from the package and check that all parts are enclosed.

Step 2. Place the plastic end caps on the open ends of the frame pieces.

Step 3. Assemble the frame pieces as shown in the diagrams with the bolts and hex nuts provided.

